



TUBESTOCK PLANTING

NOTES:

1. Drawing in millimetres unless noted otherwise.
2. All weeds shall be removed from the planting areas prior to planting.
3. The subgrade shall be cultivated to a depth of 250mm min.
4. Rocks/clods greater than 50mm shall be broken down or removed.
5. Topsoil shall not be cultivated into underlying soil layers.
6. Trees are to be of good form, health, structure and free of pests and disease. Tree species to be chosen in collaboration with the City Of Port Phillip.
7. Plant roots shall be protected from drying influences such as sun, wind and frost.
8. Thoroughly water plants prior to planting.
9. The location of plants is to be established prior to further preparation works.
10. All plants shall be set plumb in the centre of the hole and placed to ensure a normal relationship of the crown to the soil surface.
11. All non-native plants shall be fertilised with 0.5 teaspoons (5g) 'osmocote' (Long life) and water in after planting.
12. Where excavation will occur, contractor must conduct a Dial Before You Dig (www.1100.com.au).

A APPROVED FOR USE		DEC 2020
No	Revision	Date

Disclaimer:

The authors and sponsoring organisations shall have no liability or responsibility to the user or any other person or entity with respect to any liability, loss or damage caused or alleged to be caused, directly or indirectly, by the adoption and use of these Standard Drawings including, but not limited to, any interruption of service, loss of business or anticipatory profits, or consequential damages resulting from the use of these Standard Drawings. Persons must not rely on these Standard Drawings as the equivalent of, or a substitute for, project-specific design and assessment by an appropriately qualified professional.



DRAWING NOT TO SCALE		Drawing Title TUBESTOCK PLANTING
Approved	Project Services	
Date	Dec. 2020	Original Size A3 Drawing No: CPP3101
		Rev: A